



PS2 SOFTWARE DOWNLOAD GUIDE

1. Open a browser, enter the URL <http://www.xtooltech.net>, and then choose English version



2. Click the top right corner site "Register", enter the registration page. Please sign in straightly if you registered before



3. Write down product serial number, register password and the dealer number, and click "Next Step"

A screenshot of a registration form titled "MemberCenter >> Sign In". The form has a "Registered Types" dropdown set to "Product User". Below are four input fields: "Product serial number" with the value "PS2-11382", "Register Password" with the value "13456542", and "Distributor code" with the value "xtool". A "Next Step" button is at the bottom. Red boxes and arrows point to each input field with instructions: "Input the S/N(Mach Case)" for the product serial number, "Input product registration code (As the below chart)" for the register password, and "Input distributor code (Please consult dealers)" for the distributor code.

Please Power the mainframe with VCI box by cable (not wireless connection), then get the register password



4. Enter a user name, password and mailbox, Click "Submit"

5. suggesting successful register, click the "download center".

navigation

- Download center
- Payment instructions
 - Online payment
 - Other payment
- Membership Information
- Product Registration
- Exit

MemberCenter

Welcome to www.Xtooltech.net!!

Click and enter the download listing

Register the other products

6. Download the "software upgrade tool" firstly

Product User >> DownCenter

Choose VCI SN PS2-00002

Select version Select language

ID	Software Name	The Latest Version	Date Time	Downloadable version	Language of Different	Choose
*	SoftUpdate	5.5	2011-03-31	5.5	English	Download
*	PS2OS	5.5	2011-03-12	5.2	English	Download
*	PS2DISPLAY	5.5	2011-03-12	5.5	English	Download
1	BREMACH	5.2	2011-05-03	5.1	English	Download
2	ASTRA	5.2	2011-05-03	5.1	English	Download
3	ERF	5.2	2011-05-03	5.1	English	Download
4	UD	5.3	2011-05-03	5.3	English	Download
5	IVECO	5.2	2011-05-03	5.1	English	Download
6	DAF	5.3	2011-05-03	5.3	English	Download
7	OBD	5.2	2011-05-03	5.1	English	Download

7. Double click "xtoolupdate.exe" file after decompression



8. Welcome screen appears, click "Next" to install.




9. Select the target disk you want to install, and then click "next" to continue.


10. Install finished




13. Click the Top right icon and select the folder where to download the software.



14. Show the serial number and the list of upgrade software



15. Insert the SD \ TF Card Reader into the computer. Select the upgrade software; click the "upgrade."



16. Upgrade finished!